



Section B24 Spreader Covers, Lo-Stak Cars, Wind Indicators



B24.1 Spreader Covers

Leather Spreader Covers provide a smooth surface to spreader tips, thus protecting sails from undue wear. They suit most spreader situations (see Section 3). Supplied in pre-punched pairs, and complete with lacing, they are easy to fit and have a long-life expectancy.

PART NO.	TO SUIT SPREADER or DIAMOND or MASTHEAD JUMPER SET		
024.012A	A	Spreader Cover	Spreader Cover (fitted)
024.012B	B		
024.012C	C		
024.024D	D		

B24.2 Lo-Stak Batten Slides

Lo-Stak Batten Slides are a means of connecting a fully-battened mainsail luff to the mast - a cost-effective alternative to RCB systems. They have been designed to suit the integral sail tracks on Allyacht Spars mast sections, either the internal boltrope track or the external RCB track. Made from high-grade lubricated nylon, they slide very easily on the anodised mast surface, and having a low vertical profile, will enable the mainsail to be stacked to a minimal height on the mast when lowered. The connection to the mainsail luff utilises a stainless steel pin within a PVC insert, designed to accept a double thickness standard 25mm webbing strap.

PART NO.	SUIT TRACK TYPE	SUIT MAST		
024.BCR/60	Internal boltrope	IM12L IM135 IM15 IM16L IM18L IM19 IM20 IM20W IM22W	Internal boltrope	External track
024.BCR7000/60	External RF7000 track	IM18R IM21R		

B24.3 Wind Indicators

Allyacht Spars Australia usually uses Windex Wind Indicators as shown below.

PART NO.	DESCRIPTION	SUIT MAST SECTION
024.015M	Windex Wind Indicator 10"	Up to IM16L
024.015	Windex Wind Indicator 15"	IM18 and bigger