

## Section B25      Mast Mount Turning Collars

### B25.1 Mast-Mount Turning Collar

Halyards and other control lines on the mast and boom are often led from the mast back to the cockpit. Usually such lines are led through turning blocks mounted at deck level on the Deck Plate or Deck Collar, however there is sometimes the need to turn a line above deck level, such as when the deck rises behind the mast. The Mast Mount Turning Block enables this, being a turning block with a mounting that fits on to the mast at the appropriate level.

DESCRIPTION	PART NO.
Mast mount turning collar 80 x 16	025.002